



SPECIFICATIONS

Composition	Average Thickness	Carrier	Dimensions	Certifications
PU	150 µm	Adhesive & Transparent Polyester	50 cm x 5/10 m	 <p>All references: Class I</p> 

APPLICATION INSTRUCTIONS

Applies on	Cutting	Application Temp. & Duration
Cotton Polyester Acrylic Cotton/Polyester blends without repellent treatment	Use a Flex Blade 45°	160°C – 20 s 320°F – 20 s

Pressure	Peeling
Medium	Cold

Step 1 – Cutting

Set up the cutting of your heat transfer film in mirror mode and use a standard flex blade of 45°.

Step 2 – Weeding

Remove the excess of material (easy weeding).

Step 3 – Application

Position your design on the textile and press it

for 20 seconds, with a medium pressure. at 160°C/320°F
We do recommend the use of a silicone paper to protect the designs and the textile during the application.

Step 4 – Peeling

Peel the material while cold.

NOTE: We highly recommend you to perform tests before launching a production.

CARE AND MAINTENANCE RECOMMENDATIONS

Washing	Ironing	Tumble-dry	Dry cleaning
Up to 60°C/140°F	On reverse side only	Yes	Yes

Storage life	Storage Temperature & Lightning	Position
Up to 1 year	Dry room with 15°C-30°C / 59°F-86°F	Away from sunlight Vertical Position

Care and maintenance:

- ✓ Always respect the garments' instructions.
- ✓ Wait 24 hours after the application before the first wash.
- ✓ Avoid the use of aggressive products.

Washing recommendations:

- ✓ Respect the textile recommendations.
- ✓ Preferably inside out to extend the design's life.
- ✓ Do not bleach.