SpaceControl Basic

by TheMagicTouch®

QuickSetUp Guide
for OKI CMYK Printers and SpaceControl Basic.
Note: Only Windows/PC compatible via USB or static Network!
Not compatible with Mac.

1. Install Driver and Printer according OKI's original SetUp instruction. Important: Do not connect and power on your Printer and let Windows Update select a generic Driver, that will not work with SpaceControl ! If you have no DVD Drive on your PC download a PS Driver from your local OKI website at 'Support' > 'Drivers&Software' and install. Only connect and power on your Printer when the installation dialogue is asking for it!

Note: Before installing SpaceControl Basic make sure the Printer is connected via a USB or Network cable, Driver installed and powered on!

2. Install SpaceControl Basic via the SetUp.exe and follow the dialog.

3. Launch SpaceControl Basic.

4. Select the 'Utility' tab and select 'License Install'. Find the License File you received from us and select 'Open'. Your License will install and the window will close.

Note: With your first Installation SpaceControl will automatically setup the Colour Profile for the connected Printer. If you later choose to connect a different Printer Model you need to change the Colour Profile manually.

Congratulation! Your Printer is now ready to work with SpaceControl Basic by TheMagicTouch. If you encounter any trouble please contact us via: http://www.themagictouch.com/copyprob.html

© TheMagicTouch, Germany 2019, All rights reserved